

Brakes

Brake System Inspection

Refer to *Safety Precautions* on [page 118](#).


(Models equipped with center stand)

1. Place the motorcycle on its center stand, stop the engine, and place the transmission in neutral.

(Models not equipped with center stand)

1. Place the motorcycle on its side stand, stop the engine, and place the transmission in neutral.
Support the motorcycle securely, raise the rear wheel off the ground.
2. Move the left caliper assembly upward while slowly rotating the rear wheel. The brake system is normal if the rear wheel stops. If the rear wheel does not stop, see your dealer.

LEFT FRONT



LEFT REAR

