




To Change the Audio Mode




Press  switch to change the audio mode. Cycles through the audio modes on the information bar as follows:

[FM] → [AM] → [SXM] (option) → [USB] → [iPod] → [Bluetooth] → [AUX] (option)




- [FM] 
- [AM] 
- [SXM]

This function is optional. Contact your dealer for details.


- [USB] 
- [iPod] 
- [Bluetooth] 
- [AUX]


This function is optional. Contact your dealer for details.


To Select the Audio Output Device

You can switch the audio output between the paired *Bluetooth*® headsets and the speakers by pressing  button on the center panel.

The selected device is displayed by the audio output status icon on the screen.

 : Audio output is from the *Bluetooth*® headsets.

 : Audio output is from the speakers.



Audio output status icon

To Adjust the Volume

You can adjust the volume settings for the speakers and headsets separately.

The system has following unique volume levels. Adjust the volume while in the individual modes.

[Audio] / [Phone] / [Navi] / [Ring tone] / [Siri] / [Apple CarPlay] / [CB radio (option)]

When you push  lever up or down, the volume control level appears on the information bar.

