







Audio System (Continued)

Phone Setting

You can configure the phone settings. Rotate  or press \blacktriangle / \blacktriangledown on the 4-way key switch to select a setting menu item. Press  or [ENT] switch to set your selection.





The phone settings contain the following:


- [Private mode]  P. 88
- [Phonebook download]  P. 88
- [Mic. level]  P. 89

Private Mode

Enables/disables a call with the passenger's headset.

- 1 Select [Private mode], and then press  or [ENT] switch to select (enable) or deselect (disable) the function.
- 2 Return to the previous screen or the Home screen.  P. 24

Default: On (selected)

This setting can also be configured by pressing and holding  switch on the left handlebar during a call.


Phonebook Download





Enables/disables automatic import of your phonebook and call history when your phone is paired.

Up to 1,000 phonebook entries can be stored.

► For each person, you can store up to 4 numbers (home, office, cell phone and other) in the phonebook.

Phonebook is updated after every connection. Call history is updated after every connection or call.



- 1 Select [Phonebook download], and then press  or [ENT] switch.
- 2 Rotate  or press \blacktriangle / \blacktriangledown on the 4-way key switch to select [Auto] or [Manual], and then press  or [ENT] switch.
- 3 Return to the previous screen or the Home screen.  P. 24

Default: Auto