

I

Idling Stop Button.....	52
Idling Stop Indicator	46
Idling Stop OFF Indicator	40
Idling Stop System.....	28, 61
Ignition Cut-off System	
Banking Sensor	210
Side Stand.....	163
Ignition Switch	49, 110, 210
Indicators	44
INFO Button.....	48
Information Record.....	237
Instruments.....	22
INFO 1 display	34
INFO 2 display	39
INFO 3 display	41
Multi-information Display.....	23
Instruments, Controls, & Other Features.....	210
Interface Dial	48
iPhone.....	92
iPod	92

L

Labels	6
Load Limits.....	17
Loading Guidelines	17
Low Fuel Indicator.....	44
Low Oil Pressure Indicator.....	45, 175
Low Tire Pressure Indicator	44, 177

M

Maintenance	
Fundamentals.....	140
Importance	137
Safety	137
Schedule	138
Map Color	32
Maximum Weight Limit	17
MODE Button	52
Modifications.....	17
Moving in Reverse	117
MT MODE.....	113
Multi-information Display	23
Basic Operations.....	24
Helpful Information.....	27
Information bar.....	25
Navigation	23
System Information.....	27
Vehicle Information	26

N

N Switch	52, 113
Neutral Indicator	46

O

Odometer.....	36
Oil	
Engine.....	145, 154
Final Drive.....	146, 159
Overheating.....	174
Owner's Manual	130, 210
Oxygenated Fuels	227

P

Parking	15
Parking Brake.....	60
Parking Brake Indicator.....	47
Parking Brake Lever.....	60
Parts Location	18
Passenger Seat Heater	
Indicator	43, 133
Passenger Seat Heater Switch.....	54, 133
PGM-FI (Programmed Fuel Injection)	
Malfunction Indicator Lamp (MIL).....	45, 175
Phone	
To End a Call.....	107
To Make a Call.....	102
To Receive a Call.....	107
Protective Apparel.....	10

Q

Quick Engine Starting	111
-----------------------------	-----