## **Seat Heaters Failure Indication**

## GL1800/D/DA

If the seat heater system has an error, the seat heater indicator will blink.

If this occurs, see your dealer as soon as possible.

## **Coolant Temperature Gauge Failure Indication**

If the cooling system has an error, all segments will blink as shown in the illustration.

If this occurs, see your dealer as soon as possible.

