


Audio Systems

System Control

To turn the audio system on – push the AUDIO button.




(Models not equipped with Navigation System)

AUDIO button



(Models equipped with Navigation System)

AUDIO button



To turn the audio system off – push and hold the AUDIO button.

CB is optional equipment. It is only indicated if installed.