


Muting

To mute the audio and navi volume – push the MUTE button.

The display will indicate “MUTE”.


To restore the original volume – push the MUTE button again to restore the original volume.

LEFT HANDLEBAR



MUTE button

(Models not equipped with Navigation System)



(Models equipped with Navigation System)

