

Servicing Your Honda

Service Preparations

| | |
|---------------------------------------|-----|
| Maintenance Component Locations | 161 |
| Tool Kit (Canada only)..... | 164 |
| Owner's Manual Storage..... | 165 |
| Cover Removal..... | 166 |
| Clip Removal | 171 |

Service Procedures

Fluids & Filters

| | |
|--------------------------|-----|
| Fuel..... | 172 |
| Engine Oil & Filter..... | 175 |
| Coolant | 182 |
| Crankcase Breather | 185 |
| Final Drive Oil | 186 |

Engine

| | |
|---------------------|-----|
| Clutch System | 188 |
| Spark Plugs..... | 190 |

Chassis

| | |
|-----------------|-----|
| Suspension..... | 192 |
| Brakes..... | 196 |
| Tires..... | 201 |
| Side Stand..... | 208 |

Electrical

| | |
|---------------|-----|
| Battery | 209 |
|---------------|-----|

| | |
|-----------------------|-----|
| Appearance Care | 213 |
|-----------------------|-----|