

Index

| | |
|---------------------------------|--------|
| consumer information | 269 |
| controls & features | 35 |
| coolant | 182 |
| coolant temperature gauge | 15, 20 |
| crankcase breather | 185 |
| cruise control | 91 |
| customer service | 273 |

D

| | |
|---------------------------------|-----|
| defects, reporting safety | 276 |
| digital clock adjustment | 30 |
| drive, final | 186 |

E

| | |
|-------------------------------|-----|
| emission control systems..... | 263 |
| engine, | |
| flooded | 72 |
| low oil pressure | 243 |
| number | 252 |
| oil | 175 |
| overheats | 241 |
| pinging | 172 |
| starting..... | 71 |
| stop switch | 36 |
| stopping..... | 73 |
| won't start | 227 |
| environment..... | 223 |

F

| | |
|-----------------------|-----|
| fairing pocket | 59 |
| final drive oil | 186 |
| flat tire | 230 |
| flooded engine | 72 |

(cont'd)