

Shelter Case Except GL1800DA

The shelter case is for lightweight items.

Cargo should not exceed:


6.6 lb (3.0 kg)

Press the shelter case opener, the shelter case lid opens.

To close the shelter case, push the lid until it is firmly closed.

- ▶ Do not store valuables in the shelter case.
- ▶ Make sure the shelter case is closed before riding.
- ▶ Be careful not to flood this area when washing your motorcycle.

Shelter case opener



Shelter case lid


Helmet Holder

The helmet holder is located on the left grab rail.

▶ Use the helmet holder only when parked.

- 1 Open the left saddlebag. ➔ P.128 and take up the helmet holder hanger. ➔ P.132
- 2 Pull the helmet holder release lever backward to unlock the helmet holder pin.

Helmet holder pin Helmet holder release lever



- 3 Insert the helmet holder hanger into the helmet D-ring.

