


## Operating instructions



(1) HORN BUTTON

### Horn button


Press the button to sound the horn.



(1) MAGNETIC STOP SWITCH

### Magnetic stop switch

Pull the stop magnetic switch (red) until the engine stops completely.



4ED

- (1) MAPPING SWITCH
- (2) MODE 1
- (3) MODE 2

### Mapping switch

The ECU for the Cota 300RR (4ED) PGM-FI electronic injection system has two operational maps which can be selected depending on the conditions:

**Switch in Mode 1:**  
Standard

**Switch in Mode 2:**  
Powered