

Checking the brake fluid

1. Place the motorcycle in an upright position on a firm, level surface.

2. **Front**

Make sure that the brake fluid reservoir cap is in a horizontal position and that the fluid level is above the minimum level mark (MIN).

Rear

Make sure that the brake fluid reservoir is in a horizontal position and that the fluid level is between the MIN and MAX level marks.

If the brake fluid level in the brake fluid reservoirs is below the MIN level mark or there is too much free play of the brake lever or pedal, inspect the brake pads for wear. If they are not worn, a leak is likely. Have your dealer inspect the motorcycle.

Recommended brake fluid: DOT 4

Front

Front brake fluid reservoir



Rear

Rear brake fluid reservoir

