

4. Remove the dust cover.
5. Press down on the pin and pull out the bulb without turning it.
6. Install a new bulb and the rest of the parts in the reverse order of removal.

Do not touch the glass surface with your fingers. If you touch the bulb with your bare hands, clean it with a cloth moistened with alcohol.

