


Lubrication

Lubricate the cargo bed pivots as shown in following illustration.



Lubricate the cargo bed hook pivots as shown in the following illustration.

Lift the cargo bed (page 44).

