

Tire Rotation

Refer to *Safety Precautions* on page 77.

This procedure requires mechanical skill and professional tools such as a torque wrench. If you do not have the skills or the tools, see your Honda dealer.

Jack up and support the Honda MUV (page 92).

To help increase tire life and distribute wear more evenly, rotate the tires according to the Maintenance Schedule. Move the tires to the positions shown in the chart each time they are rotated.

