

# Engine Oil & Filter

---

17. Place the right under panel in the proper position.
18. Install the center panel while pulling forward the middle of the center fender.
19. Install the screws A, screws B and screws C.
20. Install the right seat mount pipe, collar A, collars B and tighten the bolt A and bolts B to the specified torque:
  - bolt A  
16 lbf·ft (22 N·m , 2.2 kgf·m)
  - bolts B  
20 lbf·ft (27 N·m , 2.8 kgf·m)
21. Install the seat and seat-back.
22. Pour the drained oil into a suitable container and dispose of it in an approved manner (page 174).

<b>NOTICE</b>
---------------

*Improper disposal of drained fluids is harmful to the environment.*