


# Lubrication

---

Lubricate the cargo bed strikers as shown in the following illustration.  
Lift the cargo bed (page 46).

## UNDER CARGO BED

### RIGHT SIDE



Lubricate the tailgate pivots as shown in following illustration.  
Open the tailgate (page 45).

