## **Exhaust System**

## **Exhaust System Inspection**

Stop the engine and check for any sign of exhaust gas leakage. Listen for exhaust leaks near the muffler, which is located by the left rear wheel well.

