

Index

storage,	
MUV	170
owner's manual	91
suspension,	
adjustment.....	136
spring pre-load.....	137
switch,	
headlight	26
ignition.....	25

T

tailgate levers	45
tires,	
air pressure.....	147
flat	183
repairing.....	151
replacing	152
thread conditions.....	149
tool kit	90
trailer hitch.....	44
trailer towing,	
operational guidelines.....	59
weight limits	59
transporting your Honda.....	168
tripmeter.....	17, 20, 23
trouble, unexpected.....	175
troubleshooting, starting	178
turning, on level ground.....	70