


Lubrication

Lubricate the cargo bed strikers as shown in the following illustration.
Lift the cargo bed (page 46).

UNDER CARGO BED RIGHT SIDE



Lubricate the tailgate pivots as shown in following illustration.
Open the tailgate (page 45).

