

# Tool Kit

---

The tool kit is stored in the tool kit compartment under the seat.

To access the tool kit, remove the seat ([page 93](#)), and then remove the rubber dust cover.

An optional, larger tool kit may be available. Check with your dealer's parts department.

## UNDER SEAT LEFT SIDE

