


Lubrication

Lubricate the brake pedal pivot and accelerator pedal pivot as shown in the following illustration.



Lubricate the parking brake pivot as shown in the following illustration. Remove the center panel ([page 130](#)).

