

Brakes


Check the pads for wear.

1. Remove the wheels ([page 184](#)).
2. Check the wear indicator groove in the pad.

If pad is worn to the bottom of the grooves, replace both pads as a set.
See your dealer for this service.


FRONT

wear indicator groove



REAR

wear indicator groove



Always inspect both pads in both the right and left brake calipers.