
Rear Utility Box

Never exceed the maximum weight capacity. **Maximum weight:** 6.6 lb (3.0 kg)



Opening the Rear Utility Box

- 1 Insert the ignition key, and turn it clockwise.
- 2 Pull the lever upwards.
 - To prevent damage, do not turn or remove the key forcibly while pulling up the lever.
- **3** Open the lid.

Closing the Rear Utility Box

- 1 Close the lid until it locks.
 - Make sure that the lid is locked securely.
- 2 Check if the lever is in original position.
- 3 Remove the ignition key.
 - The ignition key cannot be removed until the lid is locked and the lever is returned to its original position.