

## Instruments *(Continued)*

The average fuel mileage and fuel consumption will be based on tripmeter A.

- **Current fuel mileage:**  
Current instant fuel mileage. If your speed is less than 3 mph (5 km/h) or immediately after ignition switch to ON, "--:--" is displayed.  
When "--:--" is displayed at speeds above 3 mph (5 km/h), go to your dealer for service.
- **Average fuel mileage:**  
Average fuel mileage since tripmeter A was reset. It displays "--:--" after resetting the tripmeter A. When "--:--" is displayed in other cases, go to your dealer for service.
- **Fuel consumption:**  
Total fuel consumption since tripmeter A was reset. When "--:--" is displayed, go to your dealer for service.  
▶ **To reset the average fuel mileage and fuel consumption:** ( P23)