

- !e Press the SEL button until the desired day is displayed.
 - u Press and hold the SEL button to advance the day fast.



- !f Press the SET button. The date is set, and the display returns to the ordinary display.

SP Setting Mode

1 Selecting the user setting mode color:

- !a Select the SP setting mode. (P34)
 - !b Press the SEL button. The color is switched.
 - u When the ECO mode is set to on, AQUA and GREEN can not be selected.
 - u When the shift up mode is set to on, AMBER can not be selected.

