


Fuel gauge

Remaining fuel when only 1st (E) segment starts flashing:
approximately 0.394 US gal (1.45 liters)



If the fuel gauge indicators repeat flashing or turned off: ➔ P. 87

Odometer [TOTAL] & Tripmeter [TRIP] & Clock (12-hour display)

MODE switch selects the odometer, tripmeter and clock.

- Odometer: Total distance ridden.
- Tripmeter: Distance ridden since tripmeter was reset (press and hold MODE switch to reset to 0.0 mile (0.0 km)).

To set the clock: ➔ P. 22

