

Indicators & Displays

Multi-function display	This display includes the following functions.
Speedometer	Shows riding speed in miles or kilometers per hour (page 22).
Tachometer	Shows the engine rpm (page 23).
Fuel gauge	Shows approximate fuel supply available (page 24).
Odometer display	Shows the odometer, tripmeter, coolant temperature gauge, hourmeter, maintenance tripmeter and maintenance hourmeter (page 25).
Maintenance minder indicator	Shows when specified maintenance interval is reached (page 30).
Digital clock	Shows the time (hours and minutes) (page 31).
Gear position indicator	Shows the gear position (page 32).
AT/MT/SPORT/LOW indicator	Shows the transmission mode (page 33).
Drive mode indicator	Shows the driving mode (page 34).
SEL/SET switch	This switch is used to select the mode, to change the mileage unit and adjust/ resets the digital clock, tripmeter and hourmeter (page 21).