

Side Nets

Side Nets Set Up

The left and right side nets can be set up in the same manner.

Inspect the side nets and their mounting hardware for damage as specified in the maintenance schedule on page 115.

Front

1. Fasten the side net buckle.
2. Open the doors (page 45).
3. Lift the cargo bed (page 69).
4. Tighten the belts on the side net D-rings.

