

Side Nets

Side Nets Set Up

The left and right side nets can be set up in the same manner.

Inspect the side nets and their mounting hardware for damage as specified in the maintenance schedule on page 127.

Front

1. Fasten the side net buckle.
2. Open the doors (page 54).
3. Lift the cargo bed (page 81).
4. Tighten the belts on the side net D-rings.

