

Quick Reference

Scheduled Maintenance	Initial: 100 miles (150 km) Regular: every 600 miles (1,000 km)
Pre-drive Inspection	Each time before you drive (page 90): oil level, coolant, fuel level, brake fluid, tires, wheels, driveshafts, steering gearbox and boots, underbody, suspension, lights, controls, tie-rod ends, cargo, seat belts, side nets, exhaust system
Fuel/Capacity	Unleaded gasoline, pump octane number 86 or higher 7.9 US gal (30 ℓ)
Engine Oil/Sub-Transmission Oil	API Service Classification SG or higher except oils labeled as energy conserving or resource conserving on the circular API service label, SAE 10W-30, JASO T 903 standard MA, Pro Honda GN4 4-stroke oil (USA & Canada) or Honda 4-stroke oil, or an equivalent Engine oil filter and oil exchange: 6.08 US qt (5.75 ℓ) Engine oil filter, DCT oil filter and oil exchange: 6.1 US qt (5.8 ℓ) Sub-Transmission oil exchange: 1.27 US qt (1.2 ℓ)
Maximum Weight Capacity	USA - 49 states, Canada, Australia, New Zealand models: 1,649 lb (748 kg) USA - 50 states [meets California] models: 1,248 lb (566 kg) operator, passenger, all cargo and accessories