

# Servicing Your Honda

---

Air Cleaner Outer Cover Removal .....	140
Rear Mudguard Lid Removal .....	141
Clip Removal .....	142
Jack Up Point & Support Point .....	144

## *Service Procedures*

### Fluids, Filters & Lubricants

Fuel .....	145
Engine Oil & Filters .....	148
Front Final Gear Oil.....	165
Rear Final Gear Oil.....	167
Coolant .....	169
Air Cleaner .....	173
Lubrication .....	177

### Engine

Accelerator Pedal.....	182
Spark Plugs.....	184
Spark Arrester .....	187
Exhaust System.....	189

### Chassis

Suspension .....	190
Frame .....	195
Brakes .....	196
Tires .....	202
Wheels .....	210
Driveshaft Boots .....	211

### Electrical

Battery .....	212
Appearance Care.....	217