

Basic Operation & Driving Guidelines

This section gives information on how to start and stop your engine. It also provides guidelines for operating on different types of terrain, and driving with cargo.

Basic Operation	86
Starting & Stopping the Engine.....	86
Shifting Gears.....	88
Selecting a Drive Mode.....	95
Operating Launch Mode (SXS1000S4D).....	96
Parking.....	100
Driving Guidelines	101
Safe Driving Precautions	101
Off-road Driving Considerations.....	103
Basic Driving.....	105
Driving on Hills	106
Driving Through Water	109
Driving at Night.....	110