Fuel Capacity

Fuel tank capacity:


7.66 US gal (29.0 ℓ)

When there is only one segment left in the fuel gauge (page 27), fuel will be low and you should refuel as soon as possible.

Refueling Procedure

Refer to Safety Precautions on page 115.

RIGHT SIDE



- 1. Open the right rear door (page 51).
- 2. Turn the fuel fill cap counterclockwise.

(cont'd)