Fuel

3. Add fuel until the level reaches the bottom of the filler neck.

Avoid over filling the tank. There should be no fuel in the filler neck.

3 WARNING

Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine and keep heat, sparks and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.
- 4. After refueling, turn the fuel fill cap clockwise until it clicks and close the right rear door.

If you replace the fuel fill cap, use a Honda Genuine replacement part or equivalent.

NOTICE

Gasoline can damage painted and matte painted surfaces. Do not allow spilled gasoline to pool on painted and matte painted bodywork. Also, do not allow gasoline soaked rags to be placed on painted and matte painted bodywork.