


Suspension

This system has two modes: NORMAL mode and SPORT mode. You can switch between NORMAL mode and SPORT mode by pressing the FLV switch at any time when the ignition switch is turned ON (q).




NORMAL mode: This mode provides reduced damping characteristics optimized for ride comfort or casual/recreational driving.

SPORT mode: This mode provides increased damping characteristics optimized for high speed tracking and large bump absorption. If running high payload, SPORT mode can also provide added support.

You can check the current mode with the indicator box located above the steering wheel.

FLV warning indicator FLV NORMAL mode indicator



FLV SPORT mode indicator

If the FLV warning indicator comes on while driving, reduce speed and take your vehicle to a dealer as soon as possible.