

Instruments & Controls

The items listed below are described in this section.

Operation Component Locations	13
Indicators & Displays.....	16
Neutral Indicator.....	17
Reverse Indicator	17
Parking Brake Indicator	17
Differential Lock Indicator	17
High Coolant/Oil Temperature Indicator.....	17
PGM-FI Malfunction Indicator Lamp (MIL)	17
Seat Belt Indicator.....	17
Electric Power Steering (EPS) Indicator.....	18
Multi-function Display.....	21
Speedometer Display	22
Odometer Display	23
Gear position display	32
Driver Controls	33
Ignition Switch.....	33
Headlight Switch	34
AT/MT Switch (SXS700M2D/M4D only).....	35
Shift Paddles (SXS700M2D/M4D only)	36
Shift Select Lever	37
Drive Mode Select Lever.....	38
Parking Brake Lever	40
Doors	41
Side Nets	43
Seat.....	50
Seat.....	50
Rear Seat Conversion (SXS700M4/M4D only).....	51
Rear Seat Stopper Adjustment (SXS700M4/M4D only)	53

(cont'd)