

Indicators & Displays

Coolant temperature gauge failure:

If the coolant temperature system has an error, the coolant temperature gauge will blink and appear in the display, and/or high coolant/oil temperature indicator will turn on.

If this occurs, see your dealer as soon as possible.

