


Lubrication

Lubricate the door latch as shown in the following illustration. Open the door (page 41).



Lubricate the rear seat latch as shown in the following illustration.
(SXS700M4/M4D only)

