

Index

I

identification, vehicle	232
ignition switch	34
indicators,	
4WD indicator	14, 18, 23
gear position indicator	24
high coolant temperature indicator	14, 17, 220
maintenance minder indicator	32
neutral indicator	14, 17
PGM-FI indicator	14, 17
PS (Electric Power Steering) indicator (TRX420FA2 only)	17
reverse indicator	14, 17
inspection, pre-ride	55

K

key,	
lost	228
number	228
kit, tool	116

L

labels, safety	5
lamp check	15
lever,	
2WD/4WD select	35
limit, weight	60
load limits	60
loading guidelines	61
lubrication,	
engine oil	126
front final gear oil	137
rear final gear oil	134