


Indicators & Displays

NOTICE

Continuing to ride with an overheated engine can cause serious engine damage.

Coolant temperature gauge failure:

If the coolant temperature system has an error, the coolant temperature gauge (1) will blink and preferentially appear in the display, and/or high coolant temperature indicator (3) will turn on. If this occurs, see your dealer as soon as possible.



(1) coolant temperature gauge

(3) high coolant temperature indicator