

# Instruments & Controls

---

|  |    |
|--|----|
| Controls & Features .....                          | 28 |
| Fuel Valve.....                                    | 28 |
| Choke Knob .....                                   | 29 |
| Ignition Switch.....                               | 30 |
| Shift Lever .....                                  | 31 |
| Drive Mode Select Switch .....                     | 32 |
| 2WD/4WD Select Switch.....                         | 33 |
| Start Button.....                                  | 34 |
| Engine Stop Switch.....                            | 34 |
| Headlight Switch .....                             | 35 |
| Headlight Dimmer Switch .....                      | 35 |
| Starting Primer Knob .....                         | 36 |
| Recoil Starter .....                               | 36 |
| Throttle Lever .....                               | 37 |
| Gearshift Switch .....                             | 38 |
| Front Brake Lever.....                             | 39 |
| Rear Brake Lever.....                              | 39 |
| Rear Brake Pedal.....                              | 39 |
| Parking Brake .....                                | 40 |
| Flag Pole Bracket .....                            | 41 |
| Trailer Hitch.....                                 | 42 |
| Accessory Socket .....                             | 43 |
| Utility Box.....                                   | 45 |
| Storage Compartment.....                           | 46 |
| PS (Electric Power Steering) (TRX500FPA only)..... | 47 |