
## **Controls & Features**

## **Parking Brake**

## LEFT HANDLEBAR



- (1) lock lever (A) to lock
- (2) rear brake lever/parking brake lever

The lock lever (1) on the rear brake lever/parking brake lever (2) allows it to be used as a parking brake. To operate, first squeeze the rear brake lever/parking brake lever using your left hand and then lock it with the lock lever using your right hand. See *Parking* page 99.

The brake lights are activated by applying the parking brake. When using the parking brake, be sure to turn the ignition switch OFF (w) to avoid discharging the battery.