

# Index

---

## O

obstacles, riding over .....	97
odometer/tripmeter .....	23
odometer/tripmeter select button .....	14, 17, 22, 23
oil,	
differential .....	131
engine .....	120
gear case .....	129
high oil/coolant temperature indicator .....	14, 15, 17, 208
operation component locations .....	11
owner's manual storage .....	115
oxygenated fuels .....	232

## P

parking .....	99
passengers, no carrying .....	53
pavement, no riding on .....	65
pinging, engine .....	117
plug, spark .....	147
pre-ride inspection .....	55
problems, unexpected .....	198
propeller shaft boots & yoke joint boot .....	175
protective apparel .....	50
PS (Electric Power Steering) (TRX500FPA only) .....	47