

Index

| | |
|---------------------------|--------|
| service, | |
| customer | 239 |
| manuals | 236 |
| warranty | 238 |
| shift lever | 31 |
| shifting gears | 76 |
| skid plates | 174 |
| skidding or sliding | 89 |
| spark arrester | 151 |
| spark knock | 117 |
| spark plug | 147 |
| specifications | 222 |
| speedometer | 18, 19 |
| stalled engine | 73 |
| stalling on a hill | 92 |
| start button | 34 |
| starting, | |
| engine | 70 |
| troubleshooting | 200 |
| stop switch, engine | 34 |
| stopping engine | 74 |
| storage, | |
| ATV | 192 |
| compartment | 46 |
| owner's manual | 115 |
| switch, | |
| 2WD/4WD select | 33 |
| downshift | 38, 80 |
| drive mode select | 32 |
| headlight | 35 |
| headlight dimmer | 35 |
| ignition | 30 |
| upshift | 38, 80 |