

Coolant

8. Wash the radiator core (14) and radiator grill covers.

NOTICE

*Do not apply pressured water directly to the radiator core.
The pressured water can damage the radiator core.*

9. Install the removed parts in reverse order of removal.