


# Controls & Features


## Start/Over Ride Button




### LEFT HANDLEBAR



(1) start/over ride button

 START or SPEED LIMITER OVER-RIDE MODE

The start/over ride button (1) is used for starting the engine and activate the speed limiter over-ride mode. Pushing the button in starts the engine. See *Starting Procedure*, page 80.

When the engine is not running and the start/over ride button is pushed, the starter motor will crank the engine. The starter motor will not operate if the engine stop switch is in the OFF () position when the start/over ride button is pushed.

To activate the speed limiter over-ride mode, see *Front Differential Lock and Speed Limiter Over-Ride (Differential Lock Switch and Start/Over Ride Button)*, page 36.