

# Index

---

starting,	
engine .....	80
troubleshooting .....	208
stop switch, engine .....	40
stopping engine .....	85
storage,	
ATV .....	200
owner's manual .....	121
suspension,	
adjustment .....	165
spring pre-load .....	166
switch,	
4WD .....	35
differential lock .....	36
engine stop .....	40
headlight .....	41
headlight dimmer .....	41
ignition .....	34

## T

tank cover assembly removal .....	124
throttle,	
cable .....	156, 157
lever .....	43, 156, 157
tires,	
air pressure .....	177
flat .....	211
repairing .....	181
replacing .....	182
thread conditions .....	179, 180
tool kit .....	120
trailer hitch .....	48