


# Indicators & Displays


## Tripmeter

The tripmeter has two sub modes, A (3) and B (4). To change the display from tripmeter A or tripmeter B to odometer, press and release the odometer/tripmeter select button (2).



- (2) odometer/tripmeter select button
- (3) tripmeter A
- (4) tripmeter B

To reset the tripmeter to zero, press and hold the RESET button (5) for more than 2 seconds with the display in the tripmeter A or tripmeter B mode.



- (5) RESET button