



# GPS Mode

7. To select your entry:
  - To increase, tap the plus button.
  - To decrease, tap the minus button.
  - To fast change in units of 10, press and hold the plus button (to increase) or the minus button (to decrease) until the desired entry appears.
8. To enter the displayed value into the system, tap (do not hold) the GPS/WP button. The next level in the entry sequence will begin flashing.
9. To select and enter the minutes (9) — follow the same procedure used in steps 7 — 8.



(9) minute

10. To select and enter the seconds (10) — follow the same procedure used in steps 7 — 8.



(10) second

(11) tenths of second

(11)

(cont'd)